



Standard Test Method for Carbon Black—Tint Strength¹

This standard is issued under the fixed designation D 3265; the number immediately following the designation indicates the year of original adoption or, in the case of revision, the year of last revision. A number in parentheses indicates the year of last reapproval. A superscript epsilon (ϵ) indicates an editorial change since the last revision or reapproval.

1. Scope

1.1 This test method covers the determination of the tint strength of carbon black relative to an industry tint reference black (ITRB).

1.2 The values stated in SI units are to be regarded as the standard. The values given in parentheses are for information only.

1.3 *This standard does not purport to address all of the safety concerns, if any, associated with its use. It is the responsibility of the user of this standard to establish appropriate safety and health practices and determine the applicability of regulatory limitations prior to use.*

2. Referenced Documents

2.1 ASTM Standards:

D 1799 Practice for Carbon Black—Sampling Packaged Shipments²

D 1900 Practice for Carbon Black—Sampling Bulk Shipments²

D 3324 Practice for Carbon Black—Improving Test Reproducibility Using ASTM Reference Blacks²

D 4483 Practice for Determining Precision for Test Method Standards in the Rubber and Carbon Black Industries²

3. Summary of Test Method

3.1 A carbon black sample is mixed with a white powder (zinc oxide) and a liquid vehicle (soybean oil epoxide) to produce a black or gray paste. This paste is then spread to produce a surface suitable for measuring the reflectance of the mixture by means of a photo-electric reflectance meter. The reflectance of the tested sample is then compared to the reflectance of the ITRB prepared in the same manner. The tint strength of the tested sample is expressed as units of the reflectance of the ITRB divided by the reflectance of the sample and multiplied by 100.

4. Significance and Use

4.1 For the broad range of commercial rubber grade carbon blacks, tint strength is highly dependent upon particle size. Tint

strength can be used as an indication of particle size; however, tint strength is also dependent on structure and aggregate size distribution. Therefore, differences in tint strength within grades of carbon black may reflect differences other than particle size.

NOTE 1—This test method was developed primarily for the characterization of N100, N200, and N300 series carbon blacks.

5. Apparatus

5.1 *Analytical Balance*, with a sensitivity of ± 0.1 mg.

5.2 *Automatic Muller*.³

5.3 *Photometric Instrument*, capable of detecting differences in the amount of light reflectance between shades of gray.⁴ The instrument is to be operated following the manufacturer's instructions for optimum performance.

5.4 *Oven, Gravity-Convection Type*, capable of temperature regulation within $\pm 1^\circ\text{C}$ at 125°C ($\pm 2^\circ\text{F}$ at 257°F) and temperature uniformity within $\pm 5^\circ\text{C}$ ($\pm 9^\circ\text{F}$).

5.5 *Reflectance Standards*, as required for each reflectance instrument for checking calibration.

5.6 *Spatulas*, 100 to 150 mm (4 to 6 in.), two, flexible, tapered.

5.7 *Syringe*, 5-cm³, automatic refilling, reproducible to ± 0.02 cm³.

5.8 *Wiping Tissue*, absorbent and lint free.

5.9 *Paste Application Apparatus*—Any one of the following groups of equipment may be used:

5.9.1 *Apparatus for Film Drawdown Method*:

5.9.1.1 *Film Applicator*,⁵ 0.076 mm (0.003 in.) in depth.

5.9.1.2 *Polished Glass Plate*, approximately 760 by 500 by 10 mm (30 by 20 by 0.375 in.).

5.9.2 *Apparatus for Roller Spreader Method*:

³ Hoover Automatic Muller, Model M5, available from Hoover Color Corp., P.O. Box 218, State Highway 693, Hiwassee, VA 24347, has been found satisfactory for this test method.

⁴ The following instruments have been found satisfactory for this test method: Erichsen Tint Tester 527, available from T. G. Bell, Inc., 1340 Home Ave., Akron, OH 44310; Densichron Reflectometer, Catalog No. 3837, composed of the following parts: Model 1 Photometer-Linear Scale, Catalog No. 3830D; Reflection Head, Catalog No. 3832A; Regulated 6-V Transformer, Catalog No. 3834M; Reflection Tile Set (Standard), Catalog No. 3827T, available from Sargent-Welch Scientific Co., Densichron Div., 7300 N. Lander Ave., Skokie, IL 60076. This model is no longer available and the suggested replacement model 3867 B has not been found to be satisfactory. Hunter MiniScan XE or XE Plus, available from Hunter Associates Laboratory, Inc., 11491 Sunset Hills Road, Reston, Virginia 22090-5280.

⁵ Film Applicator, Catalog No. AR-3800F, available from Pacific Scientific Co., 2431 Linden Ln., Silver Spring, MD 20910.

¹ This test method is under the jurisdiction of ASTM Committee D24 on Carbon Black and is the direct responsibility of Subcommittee D24.11 on Absorptive Properties of Carbon Black.

Current edition approved May 10, 2000. Published June 2000. Originally published as D 3265 – 73. Last previous edition D 3265 – 99a.

² *Annual Book of ASTM Standards*, Vol 09.01.

5.9.2.1 Tint Roller Spreader.⁶

5.10 Desiccator.

6. Reagents and Materials

6.1 *Purity of Reagents*—Reagent grade chemicals shall be used in all tests. Unless otherwise indicated, it is intended all reagents shall conform to the specifications of the Committee on Analytical Reagents of the American Chemical Society, where such specifications are available.⁷ Other grades may be used, provided it is first ascertained that the reagent is of sufficiently high purity to permit its use without lessening the accuracy of the determination.

6.2 *Industry Tint Reference Black.*⁸

6.3 *Plasticizer, soybean oil epoxide.*⁹

6.4 *Solvent, cleaning, low toxicity, and nonflammable.*¹⁰

6.5 *Zinc Oxide, Industry Tint Zinc Oxide.*¹¹

6.6 *ASTM D-24 Standard Reference Blacks.*¹²

7. Sampling

7.1 Samples of shipments shall be taken in accordance with Practices D 1799 and D 1900.

8. Calibration and Standardization

8.1 *Standard Pastes*—Prepare pastes of the ITRB, following 9.1-9.9 for the following masses, prepare the 0.1000-g paste in duplicate:

Industry Tint Reference Black (g in 10.2 mixture)	Calibration Tint Units	Acceptable Range
0.0900	90.0	89.3 – 90.7
0.1000	100.0	99.2 – 100.8
0.1100	110.0	109.1 – 110.9
0.1200	120.0	119.0 – 121.0
0.1300	130.0	129.0 – 131.0

8.2 Densichron Reflectometer

8.2.1 Following 9.10 and 9.11, use one of the 0.1000-g (100 tint units) ITRB pastes to set the instrument to an 80 reflectance value.

8.2.2 Following 9.10 and 9.12, determine the reflectivity of the remaining 0.1000-g paste. The reflectance reading must be from 79.5 to 80.5 for the duplicate pastes to be considered acceptable.

8.2.3 If the duplicate 0.1000-g pastes are acceptable, the two are blended together using a spatula, and repeat 8.2.1 using this blend.

8.2.4 If the duplicate pastes are unacceptable, prepare another 0.1000-g paste following 9.1-9.9. Repeat 8.2.1 and 8.2.2 with the new paste, and blend it with whichever of the previous 0.1000-g pastes which will satisfy the limits of 8.2.2. Repeat 8.2.1 using this blend.

8.2.5 Following 9.10 and 9.12, determine the reflectance value for all of the remaining ITRB pastes of 8.1.

8.2.6 Calculate the tint strength for the standard pastes as follows:

$$\text{Tint Units} = 80/S \times 100 \quad (1)$$

where:

S = reflectance value of sample.

8.2.7 If the measured tint values are not within the guidelines ($\pm 0.8\%$ relative of the target tint strength values) given in 8.1, then a regression of the standard values (y value) on the measured values (x value) must be calculated using the least squares method.

NOTE 2—It is almost always necessary to develop a statistical equation to measure tint strength values.

8.2.8 The measured tint strength of all subsequent samples shall then be corrected by substituting each measured value into this linear equation and calculating the corrected value for the tint strength.

8.2.9 New registration coefficients are determined periodically, typically on a monthly basis.

8.2.10 Proper calibration and standardization of the equipment, reagents, materials, and method shall be checked on a periodic basis using the ASTM D-24 Standard Reference Blacks. The standard tint strength values and the acceptable test limit of the standard reference blacks may be found in Practice D 3324.

8.3 Erichsen Tint Tester 527:

8.3.1 Turn on the power switch and allow for 30 min warm-up.

8.3.2 Place the reflectance head on the black calibration panel and adjust the digital readout to 0.00 using the “zero” control potentiometer.

8.3.3 Following 9.10, prepare the paste drawdown for reflectance measurement.

8.3.4 Use one of the 0.1000-g ITRB pastes of 8.1 to set the instrument to read 3.00 using the calibration control potentiometer.

8.3.5 Determine the reflectivity on the remaining 0.1000-g ITRB paste. This reflectance reading must be from 2.99 through 3.01 for the duplicate pastes to be considered acceptable.

8.3.6 Follow 8.2.3 and 8.2.4.

8.3.7 Determine the reflectance value for all of the remaining ITRB pastes of 8.1.

8.3.8 Calculate the tint strength of the standard pastes as follows:

$$\text{Tint Units} = 3.00/S \times 100 \quad (2)$$

where:

S = reflectance value of sample

8.3.9 Follow 8.2.7-8.2.10 to complete calibration of the Erichsen Tint Tester.

⁶ Tint Roller Spreader, Model 1A, available from Titan Specialties, Inc., P.O. Box 2316, Pampa, TX 79066-2316 has been found satisfactory for this test method.

⁷ “Reagent Chemicals, American Chemical Society Specifications,” Am. Chemical Soc., Washington, DC. For suggestions on the testing of reagents not listed by the American Chemical Society, see “Analytical Standards for Laboratory U.K. Chemicals,” BDH Ltd., Poole, Dorset, and the “United States Pharmacopeia.”

⁸ Industry Tint Reference Black, an N-330 carbon black, is available from Titan Specialties, Inc., P.O. Box 2316, Pampa, TX 79066-2316.

⁹ *Chemical Abstracts Registry Number* 12768-71-7; “Paraplex G-62,” available from C. P. Hall Co., Technical Center, Customer Service Department, 5851 West 73rd St., Chicago, IL, 60638 (312/767-4600). Minimum order is 5 gals and order should state “Refer to ASTM D3265.” A report on the shelf life of this material is filed at ASTM Headquarters. Request RR: D24-1004.

¹⁰ 1,1,1-trichloroethane has been found satisfactory for this test method.

¹¹ Available from Forcoven Products, Inc., P.O. Box 1556, Humble, TX 77347.

¹² F-4 will be used until depleted, at which time F-5 will be used. Available from Titan Specialties, Inc., P.O. Box 2316, Pampa, TX 79066-2316.

8.4 Hunter MiniScan:

8.4.1 Calibrate the instrument using the black and white tiles.

8.4.2 Place the instrument in Setup mode. Setup instrument with XYZ color scale, D65 illuminant, 10° observer, average a minimum of 3 readings. (Note that Y corresponds to the lightness/darkness function, and thus represents the information of interest).

8.4.3 Read each of the ITRB pastes at least three times and record only the average Y value of the three readings. The Y value for the 0.1000g paste should read approximately 2.60. Calculate the tint strength of the ITRB pastes as follows:

$$\text{Tint} = 2.60/Y \times 100 \quad (3)$$

where:

Y = reflectance value of sample

8.4.4 Follow 8.2.7-8.2.10 to complete the calibration of the Hunter MiniScan.

9. Procedure

9.1 Dry the zinc oxide, ITRB, and the carbon black sample(s) for 1 h in the specified oven set at $125 \pm 1^\circ\text{C}$ ($257 \pm 2^\circ\text{F}$). Remove to a desiccator and allow to cool to room temperature.

NOTE 3—The ITRB must be dried each day a test is performed, preferably at the same time as the tested sample. Dry only the required amount, as the ITRB should not be dried repeatedly.

9.2 Weigh a sample of exactly 0.1000 g of carbon black into a weighing dish and then weigh onto the carbon black 3.7500 g of zinc oxide. For N500, N600, N700 series carbon blacks, weigh exactly 0.2000 g of carbon black and 3.7500 g of zinc oxide.

9.3 Using the syringe, place $2.20 \pm 0.02 \text{ cm}^3$ or, if preferred, 2.20 g of plasticizer in the center of the mulling plate.

NOTE 4—If the use of 2.20 cm^3 (2.20 g) of plasticizer produces an unmanageable fluid paste, then it is acceptable to use 2.00 cm^3 (2.00 g) of plasticizer for both the ITRB standard and the sample.

9.4 Place the zinc oxide and carbon black in the center of the pool of plasticizer.

9.5 Mix the three materials with a spatula, confining them as close to the center as possible; mix until they are well incorporated. Clean the material from the spatula onto the top mulling plate, maintaining minimum loss of material.

9.6 Set the muller for 25 revolutions with one extra mass on the arm equivalent to a force of 445 N (100 lbf) on the plate. Close the plates, raise the mass arm, and start the muller.

9.7 At the end of the 25-revolution cycle, lower the mass arm, and open the plates. Scrape the upper plate with a spatula to remove as much paste as possible, and transfer it to the center of the lower plate. Then, with the lower plate rotating, use the spatula to spread the paste to a flattened circle on the plate, then work all of the paste to the exact center. Repeat this step two additional times. Clean the material from the spatula onto the top mulling plate.

9.8 Repeat 9.6 and 9.7 three times, for a total of four cycles of 25 revolutions each.

9.9 Remove the paste to a smooth, clean surface, and clean

the muller plates, using a solvent and wiping tissue.

9.10 Prepare the paste for reflectance measurement by one of the following methods:

9.10.1 Film Drawdown Method:

9.10.1.1 Clean the glass plate with a wiping tissue to remove any dust particles or film.

9.10.1.2 Use a spatula to place a portion of the paste near the top edge of the glass plate.

9.10.1.3 Using a film applicator and applying moderate, consistent pressure, draw down the paste to the bottom edge in 2 to 3 s.

9.10.1.4 Pick up the applicator without removing the excess paste adhered to it; return it to the beginning of the drawdown, and again draw down the paste to the bottom edge of the glass plate in 2 to 3 s. The drawdown shall have a uniform surface approximately 65 mm (2.5 in.) wide. If the surface is not uniform, prepare another drawdown.

NOTE 5—The wet film thickness of the drawdown has a nominal thickness of 0.04 mm (0.0015 in.), or approximately one half the actual gap clearance of the applicator.

9.10.2 Roller Spreader Method:

9.10.2.1 No preparation of the paste is required, for it is placed directly on the turning roller of the tint roller spreader.

9.11 Adjust the reflectance instrument as follows:

9.11.1 Densichron Reflectometer-Film Drawdown Method:

9.11.1.1 Set the range switch on 2 and the reflection head with no filter.

NOTE 6—Use the $\frac{3}{16}$ -in. aperture if reflection head No. 3882A with the variable aperture sizes is used in place of the recommended No. 3832A.

NOTE 7—When the light source in reflection head No. 3832A is replaced, refer to the instrument instruction manual for the method of checking correct alignment of the new bulb.

9.11.1.2 Disregarding the first 75 mm (3 in.) at the top of the drawdown, set the reflection head aperture over the drawdown of the ITRB paste.

9.11.1.3 Adjust the Densichron reflectometer to read an average value of 80 for at least four readings taken at different positions. All readings shall be taken after the instrument stabilizes at a new position, usually in 15 to 20 s.

NOTE 8—The black tile working standard, supplied with the Densichron reflectometer, may be used as a secondary standard by reading its reflectance value after the Densichron reflectometer has been adjusted to an 80 average reflectance value on the ITRB paste. The tile reflectance value may be used to check for instrument drift during a series of tests.

It is necessary that the reflectance head be placed in the exact same position on the tile each time its reflectance value is read. It is also important that the standard tile be clean and free of scratches. Dirt or fingerprints can be removed easily with a solution of warm water and mild soap; use of solvents, scouring powders, etc., should be avoided.

9.11.1.4 The instrument is now correctly adjusted for reading other pastes. The value 80 is used for ITRB for making calculations in 10.1.

9.11.1.5 Remove the paste and clean the drawdown area.

9.11.2 Densichron Reflectometer-Roller Spreader Method:

9.11.2.1 With the film applicator in place and the range switch in the 0 position, use a spatula to place a portion of the ITRB paste on the turning roller.

9.11.2.2 Turn the range switch to the 2 position.

9.11.2.3 Taking no longer than 5 to 10 s, adjust the

instrument to read 80 and turn the range switch back to the 0 position.

9.11.2.4 Remove the paste and clean the roller and film applicator. Replace the film applicator.

NOTE 9—The clearance between the roller and the film applicator must be 0.102 to 0.203 mm (0.004 to 0.008 in.) for optimum testing.

9.11.2.5 The instrument is now correctly adjusted for reading other pastes. The value 80 is used for the ITRB for making calculations in 10.1.

9.11.3 *Erichsen Tint Tester 527-Film Drawdown Method:*

9.11.3.1 Follow 9.1-9.9.

9.11.3.2 Disregarding the first 75 mm (3 in.) at the top of the drawdown, set the reflectance head aperture over the drawdown of the ITRB (100 %) paste.

9.11.3.3 Adjust the Erichsen reflectometer to read an average of 3.00 for at least four readings taken at different positions.

9.11.3.4 The instrument is now correctly adjusted for reading other pastes. The value of 3.00 is used for ITRB for making calculations in 10.1.

9.11.3.5 Remove the paste and clean the drawdown area when all readings have been made.

9.12 Determine the reflectance value of the prepared paste of the test sample as follows:

9.12.1 *Densichron Reflectometer-Film Drawdown Method:*

9.12.1.1 Disregarding the first 75 mm (3 in.) at the top of the drawdown, set the Densichron reflection head aperture over the drawdown. Take at least four reflectance readings in different positions on the drawdown. All readings shall be taken after the instrument stabilizes at a new position, usually in 15 to 20 s. Record each reading and use their average as the reflectance value for the sample in 10.1.

9.12.2 *Densichron Reflectometer-Roller Spreader Method:*

9.12.2.1 Place the paste on the turning roller, and turn the range switch to the 2 position.

9.12.2.2 Taking no longer than 5 to 10 s, read the reflectance, and turn the range switch back to the 0 position. Record the reflectance, and use this value for the reflectance value for the sample in 10.1.

9.12.2.3 Remove the paste, and clean the roller and film applicator. Replace the film applicator.

9.12.3 *Erichsen-Film Drawdown Method:*

9.12.3.1 Disregarding the first 75 mm (3 in.) at the top of the drawdown, set the reflectance head aperture over the drawdown.

9.12.3.2 Take at least four readings at different positions. Record each reading and use the average as the reflectance value for the sample in 10.1.

9.12.3.3 Remove the paste and clean the drawdown area when all readings have been taken.

9.13 *Hunter MiniScan—Film Drawdown Method:*

9.13.1 Disregarding the first 75 mm (3 in.) at the top of the drawdown, set the reflectance head aperture over the drawdown.

9.13.2 Take at least 3 readings at different positions and record the average as the reflectance value for the sample in 10.1.

9.13.3 Remove the paste and clean the drawdown area when

all readings have been taken.

10. Calculation

10.1 Calculate the tint strength to the nearest 0.1 unit as follows:

$$T = [(I/S \times 100) \times M] + B \quad (4)$$

where:

T = tint units,

I = reflectance value for 0.1000-g ITRB,

S = reflectance value for the sample,

M = slope of regression equation from 8.2.7,

B = y-intercept from 8.2.7.

For N500, N600, N700 series carbon blacks, divide the tint value by 2, after applying regression equation, in order to get the final value.

NOTE 10—The regression analysis may be omitted if the ITRB calibration curve meets the requirements of 8.1.

11. Report

11.1 Report the following information:

11.1.1 Proper identification of the sample,

11.1.2 Method used in reading the paste reflectance, and

11.1.3 The result obtained from the individual determination is reported to the nearest 0.1 unit.

12. Precision and Bias

12.1 This precision and bias has been prepared in accordance with Practice D 4483. Refer to this practice for terminology and other statistical details.

12.2 The precision results in this precision and bias give an estimate of the precision as described below. The precision parameters should not be used for acceptance/rejection testing of any group of materials without documentation that they are applicable to those particular materials and the specific testing protocols that include this test method.

12.3 A type I interlaboratory precision program was conducted in 1998. Both repeatability and reproducibility represent short term (daily) testing conditions. Thirteen laboratories tested six carbon blacks twice on each of two separate days. A test result is the value obtained from a single determination. Acceptable difference values were not measured. The between operator component of variation is included in the calculated values for r and R.

12.4 The results of the precision calculations are given in Table 1.

12.5 The precision for the tint strength (pooled values) may be expressed as follows:

12.5.1 *Repeatability*—The repeatability (r) of the tint strength has been established as 2.03 %. Two single test results (or determinations) that differ by more than 2.03 % must be considered suspect and dictates that some appropriate investigative action be taken.

12.5.2 *Reproducibility*—The reproducibility (R) of the tint strength has been established as 2.96 %. Two single test results (or determinations) produced in separate laboratories that differ by more than 2.96 % must be considered suspect and dictates that some appropriate investigative action be taken.

12.6 *Bias*—In test method terminology, bias is the difference between an average test value and the reference (true) test

TABLE 1 Precision Values^A—Type 1

NOTE 1—Symbols are defined as follows:
 Sr = within laboratory standard deviation
 r = repeatability, measurement units
 (r) = repeatability, %
 SR = between laboratory standard deviation
 R = reproducibility, measurement units
 (R) = reproducibility, %

Material	Mean Value	Within laboratories			Between laboratories		
		Sr	r	(r)	SR	R	(R)
D-5 (N762)	49.9	0.42	1.19	2.39	0.57	1.60	3.21
E-5 (N660)	55.4	0.32	0.92	1.66	0.57	1.62	2.93
F-5 (N683)	57.4	0.53	1.51	2.63	0.68	1.94	3.38
B-5 (N330)	98.4	0.68	1.93	1.96	0.77	2.17	2.21
C-5 (N220)	115.9	0.66	1.88	1.62	1.02	2.89	2.50
A-5 (N135)	120.9	0.80	2.28	1.88	1.33	3.76	3.11
Pooled or Average Values	83.0	0.57	1.68	2.03	0.82	2.46	2.96

^APrecision data based on normalized tint strength

property value. Reference values do not exist for this test method since the value or level of the test property is

exclusively defined by the test method. Bias, therefore, cannot be determined.

13. Keywords

13.1 carbon black; photo-electric reflectance meter; tint strength

The American Society for Testing and Materials takes no position respecting the validity of any patent rights asserted in connection with any item mentioned in this standard. Users of this standard are expressly advised that determination of the validity of any such patent rights, and the risk of infringement of such rights, are entirely their own responsibility.

This standard is subject to revision at any time by the responsible technical committee and must be reviewed every five years and if not revised, either reapproved or withdrawn. Your comments are invited either for revision of this standard or for additional standards and should be addressed to ASTM Headquarters. Your comments will receive careful consideration at a meeting of the responsible technical committee, which you may attend. If you feel that your comments have not received a fair hearing you should make your views known to the ASTM Committee on Standards, at the address shown below.

This standard is copyrighted by ASTM, 100 Barr Harbor Drive, PO Box C700, West Conshohocken, PA 19428-2959, United States. Individual reprints (single or multiple copies) of this standard may be obtained by contacting ASTM at the above address or at 610-832-9585 (phone), 610-832-9555 (fax), or service@astm.org (e-mail); or through the ASTM website (www.astm.org).