



Standard Terminology of Fire Standards¹

This standard is issued under the fixed designation E 176; the number immediately following the designation indicates the year of original adoption or, in the case of revision, the year of last revision. A number in parentheses indicates the year of last reapproval. A superscript epsilon (ϵ) indicates an editorial change since the last revision or reapproval.

1. Scope

1.1 This terminology covers terms, related definitions, and descriptions of terms used or likely to be used in fire-test-response standards, fire-hazard-assessment standards, and fire-risk-assessment standards. Definitions of terms are special-purpose definitions that are consistent with the standard definitions but are written to ensure that a specific fire-test-response standard, fire-hazard-assessment standard, or fire-risk-assessment standard is properly understood and precisely interpreted.

NOTE 1—For additional information, refer to ASTM Policy on Fire Standards.²

2. Referenced Documents

2.1 ASTM Standards:

- D 3286 Test Method for Gross Calorific Value of Coal and Coke by the Isoperibol Bomb Calorimeter³
- E 84 Test Method for Surface Burning Characteristics of Building Materials⁴
- E 119 Test Methods for Fire Tests of Building Construction and Materials⁴
- E 152 Methods of Fire Tests of Door Assemblies⁵
- E 163 Method for Fire Tests of Window Assemblies⁵
- E 648 Test Method for Critical Radiant Flux of Floor-Covering Systems Using a Radiant Heat Energy Source⁴
- E 800 Guide for Measurement of Gases Present or Generated During Fires⁴
- E 814 Test Method for Fire Tests of Through-Penetration Fire Stops⁴
- E 906 Test Method for Heat and Visible Smoke Release Rates for Materials and Products⁴
- E 970 Test Method for Critical Radiant Flux of Exposed Attic Floor Insulation Using a Radiant Heat Energy Source⁴
- E 1317 Test Method for Flammability of Marine Surface Finishes⁴

- E 1321 Test Method for Determining Material Ignition and Flame Spread Properties⁴
 - E 1352 Test Method for Cigarette Ignition Resistance of Mock-Up Upholstered Furniture Assemblies⁴
 - E 1353 Test Method for Cigarette Ignition Resistance of Components of Upholstered Furniture⁴
 - E 1354 Test Method for Heat and Visible Smoke Release Rates for Materials and Products Using an Oxygen Consumption Calorimeter⁴
 - E 1474 Test Method for Determining the Heat Release Rate of Upholstered Furniture and Mattress Components or Composites Using a Bench Scale Oxygen Consumption Calorimeter⁴
 - E 1529 Test Method for Determining Effects of Large Hydrocarbon Pool Fires on Structural Members and Assemblies⁴
 - E 1537 Test Method for Fire Testing of Upholstered Furniture Items⁴
 - E 1590 Test Method for Fire Testing of Mattresses⁴
 - E 1623 Test Method for Determination of Fire and Thermal Parameters of Materials, Products, and Systems Using an Intermediate Scale Calorimeter (ICAL)⁴
 - E 1678 Test Method for Measuring Smoke Toxicity for Use in Fire Hazard Analyses⁴
 - E 1725 Test Method for Fire Tests of Fire Resistive Barrier Systems for Electrical System Components⁴
 - E 1776 Guide for Development of Fire-Risk-Assessment Standards⁴
 - E 1822 Test Method for Fire Testing of Stacked Chairs⁴
- #### 2.2 ISO Standards:
- ISO/IEC Guide 52 Glossary of Fire Terms and Definitions

3. Significance and Use

3.1 *Definitions*—Terms and related definitions given in Section 4 are intended for use uniformly and consistently in all fire test standards and in all fire-test-response standards, fire-hazard-assessment standards, and fire-risk-assessment standards in which they appear.

3.2 *Definitions of Terms Specific to This Standard:*

3.2.1 As indicated in Section 4, terms and their definitions are intended to provide a precise understanding and interpretation of fire-test-response standards, fire-hazard-assessment standards, and fire-risk-assessment standards in which they appear.

3.2.2 A specific definition of a given term is applicable to

¹ This terminology is under the jurisdiction of ASTM Committee E05 on Fire Standards and is the responsibility of Subcommittee E05.31 on Terminology and Editorial.

Current edition approved April 10, 2001. Published June 2001. Originally published as E 176 – 61 T. Last previous edition E 176 – 99a.

² Available from ASTM Headquarters, 100 Barr Harbor Drive, West Conshohocken, PA 19428.

³ *Annual Book of ASTM Standards*, Vol 05.05.

⁴ *Annual Book of ASTM Standards*, Vol 04.07.

⁵ Discontinued; see 1994 *Annual Book of ASTM Standards*, Vol 04.07.

the standard or standards in which the term is described and used.

3.2.3 Different definitions of the same term, appearing respectively in two or more standards, are acceptable provided each one is consistent with and not in conflict with the standard definition for the same term, that is, concept.

3.2.4 Each standard in which a term is used in a manner specially defined (see 1.1 and Section 5) should list the term and its description under the subheading, Definitions of Terms.

3.3 Definitions for some terms associated with fire issues and not included in Terminology E 176 can be found in ISO/IEC Guide 52. When discrepancies exist, the definition in Terminology E 176 shall prevail.

4. Terminology

4.1 Terms and their standard definitions within the scope of this standard are given in Section 4 in alphabetical order. Annex A1 contains the definitions of terms that are included in other fire standards.

4.2 Discussions associated with definitions are printed directly under the appropriate definition. The date following each definition or discussion indicates the year of introduction or of latest revision of that particular definition or discussion.

afterglow, *n*—emission of light, usually subsiding, from a material undergoing combustion, but occurring after flaming has ceased. (1986)⁶

assembly, *n*—a unit or structure composed of a combination of materials or products, or both. (1990)

burn, *v*—to undergo combustion. (1989)

char, *v*—to form carbonaceous residue during pyrolysis or during incomplete combustion. (1979)

char, *n*—a carbonaceous residue formed by pyrolysis or incomplete combustion. (1979)

chimney effect—upward thrust of smoke and hot gases by convection currents confined in a vertical enclosure. (1999)

combustible, *adj*—capable of undergoing combustion. (1985)

DISCUSSION—The term combustible is often delimited to specific fire-exposure conditions. For example, building materials are considered combustible if they are capable of undergoing combustion in air at pressures and temperatures that might occur during a fire in a building. Similarly, some materials that are not combustible under such conditions may be combustible when exposed to higher temperatures and pressures or to an oxygen-enriched environment. Materials that are not combustible in bulk form may be combustible in finely divided form. (1985)

combustion, *n*—a chemical process of oxidation that occurs at a rate fast enough to produce temperature rise and usually light either as a glow or flame. (See also **glow** and **smoldering**.) (1989)

combustion products, *n*—effluent produced when a material undergoes combustion. (See also **smoke** and **combustion**.) (2001)

DISCUSSION—The combustion process releases mass, in gaseous, liquid, or solid form; and generates radiant energy, as heat or light, and sometimes sound. However, the common usage of the term *combustion products* in ASTM E05 standards is only for those which have mass. (2001)

composite material, *n*—structured combination of two or more discrete materials. (2001)

effective heat of combustion, *n*—the amount of heat generated per unit mass lost by a material, product, or assembly, when exposed to specific fire test conditions. (See also **gross heat of combustion**.) (2001)

DISCUSSION—The effective heat of combustion depends on the test method and is determined by dividing the measured heat release by the mass loss during a specified period of time under the specified test conditions. Typically, the specified fire test conditions are provided by the specifications of the fire test standard that cites effective heat of combustion as a quantity to be measured. For certain fire test conditions, involving very high heat and high oxygen concentrations under high pressure, the effective heat of combustion will approximate the gross heat of combustion. More often, the fire test conditions will represent or approximate certain real fire exposure conditions, and the effective heat of combustion is the appropriate measure. Typical units are kJ/g or MJ/kg. (2001)

environment, *n*—*as related to fire*, the conditions and surroundings that may influence the behavior of a material, product, or assembly when it is exposed to ignition sources or fire. (1989)

fire, *n*—destructive burning as manifested by any or all of the following: light, flame, heat, smoke. (1988)

fire-characteristic profile, *n*—an array of fire-test-response characteristics, all measured using tests relevant to the same fire scenario, for a material, product, or assembly to address, collectively, the corresponding fire hazard. (See also **fire hazard**, **fire risk**, and **fire-test-response characteristic**.) (1993)

DISCUSSION—An array of fire-test-response characteristics in a set of data relevant to the assessment of fire hazard in a particular fire scenario. In other words, all the fire tests used would have a demonstrated validity for the fire scenario in question, for example by having comparable fire intensities. The fire-characteristic profile is intended as a collective guide to the potential fire hazard from a material, product, or assembly involved in a fire that could be represented by the laboratory test conditions. (1993)

fire endurance, *n*—a measure of the elapsed time during which a material or assemblage continues to exhibit fire resistance. (1986)

DISCUSSION—As applied to elements of buildings, it shall be measured by the methods and to the criteria defined in Test Methods E 119, E 152, E 163, or E 814.

fire exposure, *n*—process by which or extent to which humans, animals, materials, products, or assemblies are subjected to the conditions created by fire. (1991)

fire gases, *n*—the airborne products emitted by a material, product, or assembly undergoing pyrolysis or combustion, that exist in the gas phase at the relevant temperature. (1979)

fire hazard, *n*—the potential for harm associated with fire. (1989)

DISCUSSION—A fire may pose one or more types of hazard to people, animals, or property. These hazards are associated with the environment and with a number of fire-test-response characteristics of materials, products, or assemblies including but not limited to ease of ignition, flame spread, rate of heat release, smoke generation and obscuration, toxicity of combustion products, and ease of extinguishment. (1989)

⁶ Date indicates year of introduction or latest review or revision.

fire model, *n*—a physical representation or set of mathematical equations that approximately simulate the dynamics of burning and associated processes. (1992)

fire performance, *n*—response of a material, product, or assembly in a particular fire, other than in a fire test involving controlled conditions (different from **fire-test-response characteristic**). (1993)

DISCUSSION—The ASTM Policy on Fire Standards distinguishes between the response of materials, products, or assemblies to heat and flame under controlled conditions, which is fire-test-response characteristic, and under actual fire conditions, which is fire performance. Fire performance depends on the occasion or environment and may not be measurable. In view of the limited availability of fire-performance data, the response to one or more fire tests, appropriately recognized as representing end-use conditions, is generally used as a predictor of the fire performance of a material, product, or assembly. (1993)

fire performance characteristic, *n*—this term is deprecated. (See **fire-test-response characteristic** and **fire performance** (q.v.)) (1990)

fire performance test, *n*—this term is deprecated. (See **fire-test-response characteristic** and **fire performance** (q.v.))

fireproof, *adj*—an inappropriate and misleading term. Do not use. (See commentary in X1.2.) (1983)

DISCUSSION—This term was originally used to describe buildings having all noncombustible structural elements and some degree of fire resistance. However, the term has been misunderstood to mean an absolute or unconditional property, and therefore the use of the term, fireproof, is inappropriate and misleading. (1983)

fire resistance, *n*—the property of a material or assemblage to withstand fire or give protection from it. (1986)

DISCUSSION—As applied to elements of buildings, it is characterized by the ability to confine a fire or to continue to perform a given structural function, or both. (1986)

fire resistant, *adj*—See **fire resistive**, the preferred term. (1983)

fire resistive, *adj*—having fire resistance (TCG-01). (1983)

fire retardant, *n*—a deprecated term. Do not use. (1986)

fire retardant, *adj*—not a defined term. Use as a modifier only with defined compound terms: **fire-retardant barrier**, **fire-retardant chemical**, **fire-retardant coating**, and **fire-retardant treatment**. (1986)

fire-retardant barrier, *n*—a layer of material which, when secured to a combustible material or otherwise interposed between the material and a potential fire source, delays ignition and combustion of the material when the barrier is exposed to fire. (1986)

fire-retardant chemical, *n*—a chemical, which when added to a combustible material, delays ignition and combustion of the resulting material when exposed to fire. (1986)

DISCUSSION—A fire-retardant chemical can be a part of the molecular structure, an admixture, or an impregnant.

fire-retardant coating, *n*—a fluid-applied surface covering on a combustible material which delays ignition and combustion of the material when the coating is exposed to fire. (See also **flame-retardant coating**. Compare **fire-retardant barrier**.) (1986)

fire-retardant treatment, *n*—the use of a fire-retardant chemical or a fire-retardant coating. (See also **flame-retardant treatment**.) (1986)

fire risk, *n*—an estimation of expected fire loss that combines the potential for harm in various fire scenarios that can occur with the probabilities of occurrence of those scenarios. (1993)

DISCUSSION—Risk may be defined as the probability of having a certain type of fire, where the type of fire may be defined in whole or in part by the degree of potential harm associated with it, or as potential for harm weighted by associated probabilities. However it is defined, no risk scale implies a single value of acceptable risk. Different individuals presented with the same risk situation may have different opinions on its acceptability. (1993)

fire scenario, *n*—a detailed description of conditions, including environmental, of one or more of the stages from before ignition to the completion of combustion in an actual fire, or in a full scale simulation. (1997)

DISCUSSION—The conditions describing a fire scenario, or a group of fire scenarios, are those required for the testing, analysis, or assessment that is of interest. Typically they are those conditions that can create significant variation in the results. The degree of detail necessary will depend upon the intended use of the fire scenario. Environmental conditions may be included in a scenario definition but are not required in all cases. Fire scenarios often define conditions in the early stages of a fire while allowing analysis to calculate conditions in later stages. (1997)

fire test exposure severity, *n*—a measure of the degree of fire exposure; specifically in connection with Test Methods E 119, E 152, and E 163, the ratio of the area under the curve of average furnace temperature to the area under the standard time/temperature curve, each from the start of the test to the end or time of failure, and above the base temperatures 68°F (20°C). (1976)

fire-test-response characteristic, *n*—a response characteristic of a material, product, or assembly, to a prescribed source of heat or flame, under controlled fire conditions; such response characteristics may include but are not limited to ease of ignition, flame spread, heat release, mass loss, smoke generation, fire endurance, and toxic potency of smoke. (1992)

DISCUSSION—A fire-test-response characteristic can be influenced by variables of exposure such as ignition source intensity, ventilation, geometry of item or enclosure, humidity, or oxygen concentration. It is not an intrinsic property such as specific heat, thermal conductivity, or heat of combustion, where the value is independent of test variables.

A fire-test-response characteristic may be described in one of several terms. Smoke generation, for example, may be described as smoke opacity, change of opacity with time, or smoke weight. No quantitative correlation need exist between values of a fire-test-response characteristic for different materials, products, or assemblies, as measured by different methods or tested under different sets of conditions for a given method. (1992)

flame, *n*—a hot, usually luminous zone of gas that is undergoing combustion. (1991)

DISCUSSION—The luminosity of a flame is frequently caused by the presence of glowing particulate matter suspended in the hot gases. (1991)

flame front, *n*—the leading edge of a flame propagating through a gaseous mixture or across the surface of a liquid or solid. (1983)

flame resistance, *n*—the ability to withstand flame impingement or give protection from it. (1983)

flame resistant, *adj*—having flame resistance. (1983)
flame resistive, *n*—See **flame resistant**, the preferred term. (1983)

flame retardant, *n*—a deprecated term. Do not use. (1986)

flame retardant, *adj*—not a defined term. Use only as a modifier with defined compound terms: **flame-retardant chemical**, **flame-retardant coating**, and **flame-retardant treatment**. (1986)

flame-retardant chemical, *n*—a chemical, which when added to a combustible material, delays ignition and reduces flame spread of the resulting material when exposed to flame impingement. (See also **fire-retardant chemical**.) (1986)

flame-retardant coating, *n*—a fluid-applied surface covering on a combustible material which delays ignition and reduces flame spread when the covering is exposed to flame impingement. (See also **fire-retardant coating**.) (1986)

flame-retardant treatment, *n*—the use of a flame-retardant chemical or a flame-retardant coating. (See also **fire-retardant treatment**.) (1986)

flame speed, *n*—the velocity of propagation of a flame front through a gaseous mixture (fuel and oxidizer) relative to a reference point. (1982)

flame spread, *n*—See **surface flame spread**, **volumetric flame spread**. (1989)

flame spread index, *n*—a number or classification indicating a comparative measure derived from observations made during the progress of the boundary of a zone of flame under defined test conditions. (1986)

flame spread index, *n*—a comparative measure expressed as a dimensionless number, derived from visual measurements of the spread of flame vs. time in Test Method E 84. (2001)

DISCUSSION—Classifications have been developed using these values. This index is different from that derived in Test Methods E 162 or D 3675. (2001)

flameproof, *adj*—an inappropriate and misleading term. Do not use. (1983)

DISCUSSION—This term was originally used to describe the treatment of textile fabrics or other organic products to make them resistant to ignition. However, the term has been misunderstood to mean an absolute or unconditional property, and therefore the use of the term, flameproof, is inappropriate and misleading. (1983)

flammable, *adj*—(1) capable of burning with a flame under specified conditions, or (2) when used to designate high hazard, subject to easy ignition and rapid flaming combustion. (1995)

DISCUSSION—The first definition is needed as it is the definition recognized by the principal international standardization bodies, the International Electrotechnical Commission (IEC) and the International Organization for Standardization (ISO). The second definition has been the ASTM Terminology E 176 definition and is the principal definition recognized by the lay public. The terms in the second definition “easy ignition” and “rapid flaming combustion,” may seem insufficiently precise but are made precise in standards that use the terms in that way, such as standards on the fire hazards of materials (for example, NFPA 704; NFPA 321, on flammable liquids; and NFPA 55, on flammable gases). (1995)

flashover, *n*—the rapid transition to a state of total surface

involvement in a fire of combustible materials within an enclosure. (1998)

DISCUSSION—Flashover occurs when the surface temperatures of an enclosure and its contents rise, producing combustible gases and vapors, and the enclosure heat flux becomes sufficient to heat these gases and vapors to their ignition temperatures. This commonly occurs when the upper layer temperature reaches 600°C or when the radiant heat flux at the floor reaches 20 kW/m². (1998)

glow, *n*—(1) the visible light emitted by a substance because of its high temperature. (2) visible light, other than from flaming, emitted by a solid undergoing combustion. (1989)

gross heat of combustion, *n*—the maximum amount of heat per unit mass that theoretically can be released by the combustion of a material, product, or assembly; it can be determined experimentally only under conditions of high pressure and in pure oxygen (See **effective heat of combustion**).

heat flux, *n*—heat transfer to a surface per unit area, per unit time. (2001)

DISCUSSION—The heat flux from an energy source, such as a radiant heater, can be measured at the initiation of a test (such as Test Method E 1354 or Test Method E 906) and then reported as the incident heat flux, with the understanding that the burning of the test specimen can generate additional heat flux to the specimen surface. The heat flux can also be measured at any time during a fire test, for example, as described in Guide E 603, on any surface, and with measurement devices responding to radiative and convective fluxes. Typical units are kW/m², kJ/(s m²), W/cm², or BTU (s ft²). (2001)

heat release rate, *n*—the heat evolved from the specimen, per unit of time. (1998)

heat stress, *n*—(physiological) adverse condition caused by exposure to elevated temperature, radiant heat flux, or combinations of these factors. (1988)

ignition, *n*—the initiation of combustion. (1989)

DISCUSSION—The combustion may be evidenced by glow, flame, detonation, or explosion. The combustion may be sustained or transient. (1989)

ignition temperature, *n*—the lowest temperature at which sustained combustion of a material can be initiated under specified test conditions. (1990)

DISCUSSION—While the phenomenon of combustion may be transient or sustained, in fire testing practice, the ignition temperature is reached when combustion continues after the pilot source is removed. (1990)

incandescence, *n*—emission of light produced by a material when intensely heated. It can be produced with or without combustion. (1997)

mass burning rate, *n*—mass loss per unit time by materials burning under specified conditions. (1989)

noncombustible, *adj*—not combustible. (See **combustible**.) (1989)

optical density of smoke, *D*, *n*—a measure of the attenuation of a light beam passing through smoke, expressed as the common logarithm of the ratio of the incident flux, I_o , to the transmitted flux, I . ($D = \log_{10}(I_o/I)$). (1989)

orientation, *n*—the plane in which the exposed face of the specimen is located during testing. (1977)

DISCUSSION—The orientation may be vertical, horizontal or at an

angle. In the latter two cases, the specimen may be facing up or down. (1977)

oxygen consumption principle, *n*—the expression of the relationship between the mass of oxygen consumed during combustion and the heat released. (1998)

oxygen depletion, *n*—*in a fire*, reduction of oxygen (O₂) content of an atmosphere as a result of combustion. (1988)

piloted ignition, *n*—ignition of combustible gases or vapors by a pilot source of ignition (compare **spontaneous ignition**, **unpiloted ignition**). (1991)

pilot source of ignition, *n*—a discrete source of energy, such as, for example, a flame, spark, electrical arc, or glowing wire (compare **piloted ignition**, **unpiloted ignition**). (1991)

pyrolysis, *n*—process of simultaneous phase and chemical species change caused by heat (compare **smoldering**). (1991)

screening test, *n*—*as related to fire*, a fire-response test performed to determine whether a material, product, or assembly (*a*) exhibits any unusual fire-related characteristics, (*b*) has certain expected fire-related characteristics, or (*c*) is capable of being preliminarily categorized according to the fire characteristic in question. (1993)

self heating, *n*—a rise in the temperature of a material, assemblage, or product caused by internal, exothermic chemical reaction. (1985)

self ignition, *n*—See **spontaneous ignition**, the preferred term. (1985)

smoke, *n*—the airborne solid and liquid particulates and gases evolved when a material undergoes pyrolysis or combustion. (1989)

DISCUSSION—So-called chemical smokes are excluded from this definition. (1989)

smoke developed index, *n*—a comparative measure, expressed as a dimensionless number derived from measurements of smoke obscuration vs. time in Test Method E 84. (2001)

DISCUSSION—Classifications have been developed using these values. (2001)

smoke obscuration, *n*—reduction of light transmission by smoke, as measured by light attenuation. (1998)

smoke toxicity, *n*—the propensity of smoke to produce adverse biochemical or physiological effects. (See **smoke**.) (1988)

smoldering, *n*—combustion of a solid without flame, often evidenced by visible smoke. (1979)

DISCUSSION—Smoldering can be initiated by small sources of ignition, especially in dusts or fibrous or porous materials, and may persist for an extended period of time after which a flame may be produced. (1979)

spontaneous ignition, *n*—unpiloted ignition caused by an internal exothermic reaction (compare **piloted ignition**). (1991)

standard temperature/time curve (standard time/temperature curve), *n*—*in fire testing*, a graphical representation derived from prescribed time-temperature relationships and used to control furnace temperature with progressing time. (1989)

DISCUSSION—One example is found in Test Methods E 119. (1989)

superimposed load, *n*—force applied to a specimen or structure other than that associated with its own mass. (1979)

surface flame spread, *n*—the propagation of a flame away from the source of ignition across the surface of a liquid or a solid. Compare: **volumetric flame spread** and **burning velocity**. (1989)

thermal decomposition, *n*—a process of extensive chemical species change caused by heat (different from thermal degradation, *q.v.*; compare **pyrolysis**). (1992)

thermal degradation, *n*—a process whereby the action of heat or elevated temperature on a material, product, or assembly causes a loss of physical, mechanical, or electrical properties (different from **thermal decomposition**, *q.v.*). (1992)

toxicity, *n*—the propensity of a substance to produce adverse biochemical or physiological effects. (1988)

toxic hazard, *n*—*as related to fire*, the potential for physiological harm from toxic products of combustion. (1995)

DISCUSSION—Toxic hazard reflects both the quantity of toxic products and the quality of those products, which is given by toxic potency. Toxic hazard is not the only hazard associated with fire. Toxic hazard is not an intrinsic characteristic of a material or product but will depend upon the fire scenario, the condition of use of the material or product, and possibly other factors. (1995)

toxic potency, *n*—*as applied to inhalation of smoke or its component gases*, a quantitative expression relating concentration and exposure time to a particular degree of adverse physiological response, for example, death, on exposure of humans or animals. (1991)

DISCUSSION—The toxic potency of the smoke from any material, product, or assembly is related to the composition of that smoke which, in turn, is dependent upon the conditions under which the smoke is generated. (1991)

unpiloted ignition, *n*—ignition caused by one or more sources of energy without the presence of a pilot source of ignition (compare **piloted ignition**, **spontaneous ignition**). (1991)

upholstered, *adj*—covered with material (as fabric or padding) to provide a soft surface. (1999)

volumetric flame spread, *n*—flame propagation through the volume of a gaseous mixture. (1989)

(Mandatory Information)

A1. DEFINITIONS OF TERMS

A1.0.1 Terms, their definitions, and the standard(s) to which they apply are given below in alphabetical order:

air drop, *n*—lengths of open run conductors or cables supported only at each end. (1995) **E 1725**

attic, *n*—an accessible enclosed space in a building immediately below the roof and wholly or partly within the roof framing. (1996) **E 970**

backing board, *n*—a noncombustible insulating board, mounted behind the specimen during actual testing to satisfy the theoretical analysis assumption of no heat loss through the specimen. It shall be roughly 25 ± 5 mm thick with a density no greater than 200 ± 50 kg/m³. (1997) **E 1321**

batch sampling—sampling over some time period in such a way as to produce a single test sample for analysis. (1981) **E 800**

blackbody temperature, *n*—the temperature of a perfect radiator—a surface with an emissivity of unity and, therefore, a reflectivity of zero. (1997) **E 648**

bolster, *n*—pillow or similarly shaped unit containing upholstery material covered by upholstery cover material that may or may not be attached to the upholstered furniture item but is sold and delivered with it. (1994) **E 1352**

carboxyhemoglobin saturation, *n*—the percent of blood hemoglobin converted to carboxyhemoglobin from reaction with inhaled carbon monoxide. (1996) **E 1678**

combustion products—airborne effluent from a material undergoing combustion; this may also include pyrolysates. (1981) **E 800**

concentration-time curve, *n*—a plot of the concentration of a gaseous toxicant as a function of time. (1996) **E 1678**

corridor, *n*—an enclosed space connecting a room or compartment with an exit. The corridor may include normal extensions, such as lobbies and other enlarged spaces. (1997) **E 648**

compensating thermocouple, *n*—a thermocouple for the purpose of generating an electrical signal representing long-term changes in the stack metal temperatures wherein a fraction of the signal generated is subtracted from the signal developed by the stack-gas thermocouples. (1997) **E 1317**

critical flux at extinguishment, *n*—a flux level at the specimen surface corresponding to the distance of farthest advance and subsequent self-extinguishment of the flame on the centerline of a specimen. (1997) **E 1317**

DISCUSSION—The flux reported is based on calibration tests with a special calibration dummy specimen.

critical radiant flux, *n*—the level of incident radiant heat energy on the floor covering system at the most distant flame-out point. It is reported as W/cm²(Btu/ft² · s). (1997) **E 648**

critical radiant flux, *n*—the level of incident radiant heat energy on the attic floor insulation system at the most distant

flame-out point. It is reported as W/cm²(or Btu/ft² · s). (1996) **E 970**

Ct product, *n*—the concentration-time product in ppm · min obtained by integration of the area under a concentration-time curve. (1996) **E 1678**

deck, *n*—the upholstered support under the seat cushion in a loose-seat construction. (1994) **E 1352**

deck, *n*—*in upholstered furniture*, the upholstered support under the seat cushion in a loose seat construction. (1994) **E 1353**

dummy specimen, *n*—a noncombustible (as defined by 46 CFR 164.009) specimen used for standardizing the operating condition of the equipment, roughly 20 mm in thickness with a density of 750 ± 100 kg/m³. (1997) **E 1317**

dummy specimen, *n*—a noncombustible insulating board used for stabilizing the operating condition of the equipment, mounted in the apparatus in the position of the specimen and removed only when a test specimen is to be inserted. It shall be roughly 20 ± 5 mm in thickness with a density of 750 ± 100 kg/m³. (1997) **E 1321**

DISCUSSION—For the ignition tests, the dummy specimen board shall have a hole at the 50-mm position for mounting the fluxmeter.

effective heat of combustion, *n*—the measured heat release divided by the mass loss for a specified time period. (1997) **E 1474, E 1354**

effective heat of combustion, *n*—the measured heat release divided by the mass loss for a specific time period. (1994) **E 1623**

effective thermal property, *n*—thermal properties derived from heat-conduction theory applied to ignition/flame-spread data treating the material as homogenous in structure. (1997) **E 1321**

electrical system components, *n*—cable trays, conduits and other raceways, open run cables and conductors, cables, conductors, cabinets, and other components, as defined or used in the National Electrical Code, and air drops as defined in A1.1.1. (1995) **E 1725**

emissivity, *n*—the ratio of the power per unit area radiated from a material's surface to that radiated from a black body at the same temperature. (1994) **E 1623**

fire-resistive barrier system, *n*—a specific construction of devices, materials, or coatings installed around, or applied to, the electrical system components. (1995) **E 1725**

fire stop—a through-penetration fire stop is a specific construction consisting of the materials that fill the opening around penetrating items such as cables, cable trays, conduits, ducts, and pipes and their means of support through the wall or floor opening to prevent spread of fire. **E 814**

fire test, *n*—a procedure, not necessarily a standard test method, in which the response of materials to heat or flame (or both) under controlled conditions is measured or otherwise described. (1981) **E 800**

- fire-test-response-characteristic index**, *n*—a single quantitative measure that combines two or more fire-test-response characteristics for a material, product, or assembly, all developed under test conditions compatible with a common fire scenario, addressing collectively the corresponding threat. See also *fire-test-response-characteristic profile*, *fire hazard*, *fire risk*, *fire-test-response characteristic*. (1996) **E 1776**
- fire-test-response-characteristic profile**, *n*—array of fire-test-response characteristics for a material, product, or assembly, all developed under test conditions compatible with a common fire scenario, addressing collectively the corresponding threat. See also *fire hazard*, *fire risk*, *fire-test-response characteristic*. (1996) **E 1776**
- flame-out**, *n*—the time at which the last vestige of flame or glow disappears from the surface of the test specimen, frequently accompanied by a final puff of smoke; Time 0 is the time at which the specimen is moved into the chamber and the door closed. (1997) **E 648**
- flux profile**, *n*—the curve relating incident radiant heat energy on the specimen plane to distance from the point of initiation of flaming ignition, that is, 0 cm. (1997) **E 648**
- fractional exposure dose (FED)**, *n*—the ratio of the Ct product for a gaseous toxicant produced in a given test to that Ct product of the toxicant which has been determined statistically from independent experimental data to produce lethality in 50 % of test animals within a specified exposure and postexposure time. Since the time values in this ratio numerically cancel, the FED also is simply the ratio of the average concentration of a gaseous toxicant to its LC₅₀ value for the same exposure time. When not used with reference to a specific toxicant, the term FED represents the summation of FEDs for individual toxicants in a combustion atmosphere. (1996) **E 1678**
- fume stack**, *n*—a box-like duct with thermocouples and baffles through which flames and hot fumes from a burning specimen pass whose purpose is to permit measurement of the heat release from the burning specimen. (1997) **E 1317**
- furniture mock-up or assembly**, *n*—a representation of production furniture that uses the same upholstery cover material and upholstery material, constructed in the same manner as in production furniture, but with straight, vertical sides. (1994) **E 1352**
- gas phase ignition**, *n*—ignition of pyrolysis products leaving a heated surface by a pilot flame or other ignition source that does not impinge on nor significantly affect (by re-radiation) the heated surface. (1997) **E 906**
- heat for ignition**, *n*—the product of time from initial specimen exposure until the flame front reaches the 150-mm position and the flux level at this position, the latter obtained in prior calibration of the apparatus. (1997) **E 1317**
- heat for sustained burning**, *n*—the product of time from initial specimen exposure until the arrival of the flame front, and the incident flux level at that same location as measured with a dummy specimen during calibration. (1997) **E 1317**
- heating flux**, *n*—the prescribed incident flux imposed externally from the heater onto the specimen at the initiation of the test. (1997) **E 1354**
- heating flux**, *n*—the incident flux imposed externally from the heater on the specimen at the initiation of the test. (1996) **E 1623, E 1474**
- DISCUSSION—The specimen, once ignited, also is heated by its own flame.
- heat release rate**, *n*—the heat evolved from the specimen, expressed per unit area of exposed specimen area per unit of time. (1997) **E 1354**
- heat release rate**, *n*—the heat evolved from the specimen per unit of time. (1996) **E 1474**
- heat release rate**, *n*—the heat evolved from the specimen per unit of time and area. (1994) **E 1623**
- ignitability**, *n*—the propensity to ignition, as measured by the time to sustained flaming, in seconds, at a specified heating flux. (1997) **E 1623, E 1354**
- ignitability**, *n*—the propensity for ignition, as measured by the time to sustained flaming at a specified heating flux. (1996) **E 1474**
- LC₅₀**, *n*—a measure of lethal toxic potency; the concentration of gas or smoke calculated statistically from concentration-response data to produce lethality in 50 % of test animals within a specified exposure and postexposure time. (1996) **E 1678**
- marine board**, *n*—an insulation board of 750 ± 100 kg/m³ density that meets the noncombustibility criteria of 46 CFR 164.009. (1997) **E 1317**
- mass loss concentration**, *n*—the mass loss of a test specimen per unit exposure chamber volume in g · m⁻³. (1996) **E 1678**
- mattress**, *n*—a mattress is a ticking (outermost layer of fabric or related material) filled with a resilient material, used alone or in combination with other products, intended or promoted for sleeping upon. (1996) **E 1474**
- measured heat release of specimen**, *n*—the observed heat release under the variable flux field imposed on the specimen and measured. (1997) **E 1317**
- mirror assembly**, *n*—a mirror, marked and aligned with the viewing rakes, used as an aid in quickly identifying and tracking the flame front progress. (1997) **E 1321, E 1317**
- net heat of combustion**, *n*—the oxygen bomb (see Test Method D 3286) value for the heat of combustion, corrected for gaseous state of product water. (1997) **E 1623, E 1354**
- obvious ignition**, *n*—pronounced continuous and self-sustaining combustion of the test system accompanied by rapid generation of heat and smoke. It is a matter of operator judgment based upon experience in this type of operation. (1994) **E 1353**
- orientation**, *n*—the plane in which the exposed face of the specimen is located during testing, either vertical or horizontal facing up. (1997) **E 1354**
- oxygen consumption principle**, *n*—the expression of the relationship between the mass of oxygen consumed during combustion and the heat released. (1997) **E 1354**
- post-flashover**, *adj*—the stage of a fire at which the average air temperature in the upper half of the room exceeds 600°C. (1996) **E 1678**
- product**, *n*—the upholstered furniture for which information is required. (1996) **E 1537**

product, *n*—mattress, or mattress with foundation, for which fire-test-response characteristics are to be measured. (1996)
E 1590

quilted, *n*—fused or stitched with thread through the upholstery cover material and one or more layers of upholstery material. (1994)
E 1352

radiant flux profile, *n*—the graph relating incident radiant heat energy on the specimen plane to distance from the point of initiation of flaming ignition, that is, 0 mm. (1996)
E 970

reverberatory wires, *n*—a wire mesh located in front of, but close to, the radiating surface of the panel heat source which serves to enhance the combustion efficiency and increase the radiance of the panel. (1997)
E 1317

sample integrity—the unimpaired chemical composition of a test sample upon the extraction of said test sample for analysis. (1981)
E 800

sampling—a process whereby a test sample is extracted from a fire test environment. (1981)
E 800

smoke developed index, *n*—a number or classification indicating a comparative measure derived from smoke obscuration data collected during the test for surface burning characteristics.
E 84

smoke obscuration, *n*—reduction of light transmission by smoke, as measured by light attenuation. (1997)
E 1354

SMOKE unit, *n*—the concentration of smoke particulates in a cubic metre of air that reduces the percent transmission of light through a 1-m path to 10 %. SMOKE = standard metric optical kinetic emission. (1997)
E 906

special calibration board, *n*—a specially assembled noncombustible insulating board used for standardizing the operating condition of the equipment which is used only to measure the flux distribution at specified intervals along the specimen surface. It shall be roughly 20 ± 5 mm in thickness with a density of 750 ± 100 kg/m³. (1997)
E 1321

special calibration dummy specimen, *n*—a dummy specimen made of the same material as the dummy specimen, intended only for use in calibration of flux gradient along the specimen. (1997)
E 1317

specimen, *n*—manufactured item of the product, representative prototype of the product, or mock-up of the product. (1996)
E 1537

specimen, *n*—the manufactured item of the product, or representative prototype of the product. (1996)
E 1590

specimen, *n*—a construction consisting of electrical system components and a fire-resistive barrier system. (1995)
E 1725

stacking chair, *n*—chair that is intended to be stacked when not in use.
E 1822

surface flame spread, *n*—the propagation of a flame away from the source of ignition across the surface of the specimen.
E 84

sustained flaming, *n*—existence of flame on or over most of the specimen surface for periods of at least 4 s. (1997)
E 1354

DISCUSSION—Flaming of less than 4 s duration is identified as flashing or transitory flaming.

sustained flaming, *n*—the existence of flame on or over the

surface of the specimen for a period of 4 s or more. (1996)
E 1474

sustained flaming, *n*—existence of flame on or over the surface of the specimen for periods of 5 s. (1994)
E 1623

DISCUSSION—Flaming of less than 4 s duration is identified as flashing or transitory flaming.

test assembly—the wall or floor into which the test sample(s) is (are) mounted or installed. (1981)
E 814

test assembly, *n*—horizontal or vertical construction on which test specimens are to be mounted together with associated instrumentation. (1995)
E 1725

test sample—a representative part of the experimental environment (gases, liquids, or solids) for purposes of analysis. (1981)
E 800

test specimen, *n*—the fire stop being tested.
E 814

test specimen, *n*—stack of five identical stacking chairs.
E 1822

thermal operating level, *n*—the operating condition at which the radiance of the heat source produces a specified constant heat flux to some specified position at the specimen surface. (1997)
E 1321

thermally thick, *n*—the thickness of a medium that is large enough to have the predominate thermal (temperature) effects experienced within that distance, that is, negligible heat is lost from its unexposed side. (1997)
E 1321

total cold wall heat flux, *n*—the heat flux that would be transferred to an object whose temperature is 70°F (21°C).

total flux meter, *n*—the instrument used to measure the level of radiant heat energy incident on the specimen plane at any point. (1997)
E 970, E 648

tufted, *n*—buttoned or laced through the upholstery cover material and upholstery material.

upholstered, *n*—covered with material (as fabric or padding) to provide a soft surface. (1994)
E 1353

upholstered, *adj*—covered with material (as fabric or padding) to provide a soft surface. (1996)
E 1474

upholstery cover material, *n*—the outermost layer of fabric or related material used to enclose the main support system or upholstery materials, or both, used in the furniture item. (1994)
E 1352

upholstery cover material, *n*—the outmost layer of fabric or related material used to enclose the main support system or upholstery materials, or both, used in the furniture item. (1994)
E 1353

upholstered furniture, *n*—a unit of interior furnishing that (1) contains any surface that is covered, in whole or in part, with a fabric or related upholstery cover material, (2) contains upholstery material, and (3) is intended or promoted for sitting or reclining upon. (1994)
E 1353, E 1352

upholstery material, *n*—the padding, stuffing, or filling material used in a furniture item, which may be either loose or attached, enclosed by an upholstery cover material, or located between the upholstery cover material and support system, if present. (This includes, but is not limited to, material, such as foams, cotton batting, polyester fiberfill, bonded cellulose, or down). (1994)
E 1353, E 1352

viewing rakes, *n*—a set of bars with wires spaced at 50-mm intervals for the purpose of increasing the precision of timing

the flame front progress along the specimen. (1997)
E 1321, E 1317

welt, n—the piping effect produced when welt cord and cover fabrics are sewn together for ornamental purposes to finish the edges between intersecting surfaces of upholstered furniture cushions, pillows, arms, or backs. (1994) **E 1353, E 1352**

welt cord, n—the continuous small-diameter cylindrical material that is wrapped in fabric and sewn as part of the cover to make a welt edge on upholstered furniture. (1994)
E 1352

APPENDIXES

(Nonmandatory Information)

X1. HISTORICAL COMMENTARY

X1.1 In the 1970's ASTM decided to develop a Policy on Fire Standards. At the same time, the ASTM Committee on Terminology (COT) created a Terminology Coordinating Group under its auspices. This Terminology Coordinating Group was designated TCG-01. It consisted of representatives of Committee E05 on Fire Standards, COT and other interested technical committees.

X1.2 The responsibility of TCG-01 was to consider and recommend terms and definitions in the field of fire technology for the purpose of minimizing redundancies and eliminating conflicts in such terminology.

X1.3 That committee recommended several definitions,

many of which have been amended over the years. Such definitions have included: afterglow, char (both as a noun and as a verb), fire exposure, fire gases, fire resistant (inappropriate and misleading), fire resistive, flame, flame front, flame resistance, flame resistant, flame resistive (as a less satisfactory alternative to flame resistant), flash point, glow, ignition, mass burning rate, optical density of smoke, piloted ignition, smoke, spontaneous ignition, surface flame spread rate, temperature and unpiloted ignition. Not all of these terms are still included in Terminology E 176 and some of the definitions have since been amended.

X2. KEYWORDS

X2.1 Scope

X2.1.1 This appendix of keywords is provided as a resource and a convenience to aid in providing index and keyword items for fire standards of Committee E-5 as well as other ASTM Committees preparing fire standards. The list has been compiled from a list prepared by the Subcommittee at the time when mandatory keyword sections were first being added to most ASTM standards. Other appropriate keywords may apply.

X2.2 Guidelines

X2.2.1 Keywords should be selected on the basis of those that best represent the technical information presented in the standard.

X2.2.2 Select the keywords from the title and body of the standard and include general, vernacular and trade terms.

X2.2.3 Select three or more keywords that describe the names of tests, procedures, special materials, or the specific application(s) that will facilitate the identification and retrieval of the standard.

X2.2.4 All selected keywords should be stand-alone terms; the type of standard, incomplete phrases, unattached adjectives, and so forth should not be used.

X2.3 Resource List of Keywords

acid gases
 activation energy

acute toxicity
 afterburner
 afterburning
 afterglow
 air leakage
 air mixtures
 air ratio
 air movement
 air velocity
 analyzer
 anhydrous fuels
 animal models atmospheric
 animal atmosphere
 anoxia
 asphyxia
 autoignition
 autoignition temperature
 autoxidation
 axisymmetric
 behavior models
 bench scale tests
 blackbody
 blackbody temperature
 building code
 buoyant flumes

buoyant flow	convection
burn room	convective heat transfer
burnout parameter	corner test
burnout	corridor test
burn through	corridor test, quarter scale
burner	crib fire
burning	crib test
burning velocity	crib
burning rate	critical temperature
burning brand test	critical radiant flux
cable insulation	critical flux for spread
cable jacket	critical irradiance
cable trays	critical temperature ignition
cable sheath	critical flux for ignition
calibrate	damper
calibration burner	decomposition
calorimeter	deformation
calorimetry	degradation
candle	deluge
carbon monoxide	detection systems
carbon balance method	differential pressure
carbon dioxide	diffusion fire
carboxyhemoglobin	diffusion flame
ceiling jet	diffusivity
cellulosic fuel	door assemblies
chamber	dosage
char	dosimeter
char depth characteristic	drape
characteristic time	dual l _{cs}
charring	dummy specimen
chimney	effective heat of combustion
cigarette ignition	effective thermal properties
cigarette test method	egress
combustibility	electrical cable
combustible properties	emission
combustible elements	emissivity
combustible	emittance
combustion gases	enclosure environment
combustion toxicity	enclosure fire
combustion efficiency	endothermic
combustion products	energy balance
combustion rate	enthalpy
combustion theory	entrainment
combustion temperature	entropy
combustion toxicology	evacuation
combustion test	event
combustion	exhaust duct
cumulative smoke release	exhaust gases
compartment fire	exhaust velocity
compartment	exit
conductive heat transfer	exothermic
conduction	experimental animals
conductivity	experimental design
cone calorimeter	explosion
cone corrosimeter	exposure
confined conical heater	extinction
conical heater	extinction coefficient
containment	extinction time

extinguish	fire statistic
extinguisher	fire stop
fabric flammability	fire test
fabric flammability testing	fire test chamber
false alarm	fire test response
fatality	fire test response standard
fault trees	fire tube apparatus
field models	fire tube assembly
fire	fire test response
fire area	fire test response standard
fire behavior	fire wall
fire brand	fireball
fire chemistry	firebox
fire code	firestop
fire containment	flame
fire containment walls	flame emissivity
fire characteristic index	flame entrainment coefficient
fire characteristic profile	flame extinction coefficient
fire control	flame front
fire effect	flame heating parameter
fire effluent	flame heat transfer factor
fire endurance	flame propagation
fire endurance test	flame radiation
fire exposure	flame region
fire gases	flame resistance
fire hazard	flame resistant
fire hazard analysis	flame retardant chemical
fire hazard assessment	flame retardant coating
fire incident	flame retardant treatment
fire model	flame speed
fire penetrations	flame spread
fire performance	flame spread rate
fire physics	flame spread test
fire point	flame temperature
fire prediction	flame travel rate
fire prevention	flame spread classification
fire propagation	flame spread index
fire propagation index	flame velocity
fire properties	flameless
fire protection	flameout
fire research	flameover
fire resistance	flameproofing
fire resistive	flaming
fire resistive material	flaming combustion
fire retardant barrier	flaming ignition
fire retardant chemical	flammability
fire retardant coating	flammability apparatus
fire retardant treatment	flammability limits
fire risk	flammability measurements
fire risk analysis	flammability tests
fire risk assessment	flammable gases
fire risk assessment standard	flammable liquids
fire safety	flammable materials
fire scenario	flammable solids
fire severity	flashpoint
fire simulation	flashback
fire size	flashover
fire spread	floor radiant panel tests

flue
 flux
 flux distribution
 flux gage
 flux profile
 flux time products
 flux uniformity
 fluxmeter
 flying brand test
 forest fuels
 fractional radiation
 free burning fires
 free convection
 free radical
 free ventilation
 froude number
 fuel
 fuel-air
 fuel-air ratio
 fuel-contributed index
 fuel load
 full-scale fire tests
 furnace
 furniture calorimeter
 gas air
 gases
 gas density
 gas phase ignition
 gas velocity
 gasification
 glow
 gravimetric soot sampler
 graybody radiation
 halon
 hazard
 hazard analysis
 hazard assessment
 hazardous materials
 hazardous vapors
 heat
 heat balance
 heat capacity
 heat feedback
 heat flow
 heat flux coefficient
 heat loss
 heat of activation
 heat of combustion
 heat of gasification
 heat of pyrolysis
 heat of reaction
 heat of solution
 heat of vaporization
 heat release
 heat release fraction
 heat release rate
 heat resistant coatings
 heat resistant materials
 heat resistant plastics
 heat transfer
 heat transfer coefficient
 heat transport
 heater
 heating
 heating flux
 heating tests
 homogeneous gas reactions
 homogeneous mixtures
 hose stream test
 hydrant
 hydrocarbon combustion
 hydrocarbon fuel
 hydrocarbon pool fires
 hyperbaric
 hyperoxia
 hypoxemia
 hypoxia
 ic50
 ideal gas law
 ignitability
 igniter
 igniting burner
 ignition burner
 ignition
 ignition circuit
 ignition correlation parameter
 ignition resistance
 ignition source
 ignition temperature
 ignition tests
 ignition time
 incandescence
 incendiary
 incinerator
 index
 induction
 inert
 infrared
 inhalation toxicity
 input
 intensity
 interior finish
 intermittent flame exposure
 intumescence test
 intumescent
 intumescent coatings
 irradiance
 irradiation isothermal
 jet entrainment
 jet flames
 kindling
 kinetic
 laminar burning
 laminar burning velocity
 laminar flame propagation
 laminar flames

laminar flow
 laminar heat transfer
 laminar jet flames
 laminar mixing
 large scale tests
 laser extinction beam
 latent heat
 lateral flame spread
 lc50
 lc (ct) 50
 life hazards
 life safety
 lift apparatus
 light
 light absorption
 light extinction beam
 light intensity
 light path
 limiting oxygen index
 liquid fuel
 luminous flames
 mass burning rate
 mass flow
 mass loss
 mass loss rate
 mass optical density
 mass transfer
 mass transfer rate
 mathematical models
 measurement methods
 medium scale tests
 melting point
 methenamine pill
 methodology
 model
 model validation
 model verification
 modeling
 moisture
 mortality
 mounting methods
 multiple lc50
 multiroom fires
 multiventilation
 national fire incident reporting system (nfirs)
 net heat of combustion
 noncombustibility
 noncombustibles
 nonconductor
 nonflaming
 nonflaming combustion
 nonignition
 non-load bearing
 nonluminous
 nonthermal damage
 occupational hazards
 occupancy
 occupancy classification
 offgassing
 Ohio State University
 Ohio State University model
 opacity
 optical calibration filters
 optical density
 optical path length
 optical properties
 output
 oven
 overheating
 oxygen concentration
 oxygen consumption
 oxygen consumption calorimeter
 oxygen consumption principle
 oxygen index
 oxygen index test
 particulate mass concentration
 party-wall
 pathological effects
 permeability
 photochemical oxidation
 photochemical reaction
 photometer
 physiological effects
 pill test
 pilot
 pilot burner
 pilot flame
 pilot source of ignition
 piloted ignition
 plasma
 plenum cable
 plume
 plume entrainment coefficient
 pool fire
 post-fire
 post-flashover
 post-ignition
 postheating
 potential heat
 precombustion
 prefire
 preflashover
 preignition
 propagation
 purposeful ignition
 pyrolysis
 pyrolysis front
 pyrolysis temperature
 pyrometer
 radiant combustion apparatus
 radiant energy
 radiant flux
 radiant flux profile
 radiant heat
 radiant heat fill

radiant heat furnace
 radiant heat source
 radiant heat transfer
 radiant panel test method
 radiation
 radiation absorption
 radiation exposure
 radiometer
 rate of heat release
 rate of mass loss
 rate of smoke release
 refractory tube method
 release rates
 residence time
 residual flame time
 residue
 response surface method
 response time
 restraint
 reynolds number
 risk
 risk analysis
 risk assessment
 risk elements
 risk rating factors
 room burns
 room fire tests
 room fires
 scale effect
 scaling
 scenario
 scorching
 screening test
 self propagating flux
 self extinguishment
 self-heating
 side wall sprinkler systems
 skin burns
 small scale fire test
 smoke
 smoke control
 smoke corrosivity
 smoke damage
 smoke density
 smoke density chamber (e 662)
 smoke density index
 smoke emission factor
 smoke filling
 smoke flow
 smoke generations
 smoke measurement
 smoke movement
 smoke obscuration
 smoke opacity
 smoke penetration
 smoke release
 smoke release rate
 smoke toxicity
 smoke unit
 smoke yield
 smoldering
 smoldering combustion
 smoldering ignition
 solid fuels
 solid propellant ignition
 soot
 soot formation
 soot sampling
 spark
 specific extinction area
 specific heat
 specific optical density
 specific smoke extinction area
 spontaneous combustion
 spontaneous ignition
 sprinkler
 sprinkler system
 stack
 stack action
 stack effect
 stagnation
 standard fire tests
 standard flammability apparatus
 standard temperature time curve
 steady state combustion
 steady state gasification
 steiner tunnel
 stephan-boltzman constant
 stoichiometric ratio
 stove
 stratification
 stratified flow
 sublimation
 substrate
 superimposed load
 suppression
 suppression devices
 surface emissivity
 surface flame spread
 surface flame spread rate
 sustained flaming
 temperature
 temperature effects
 temperature gradients
 temperature measurements
 temperature rise
 temperature tests
 thermal analysis
 thermal conductivity
 thermal damage
 thermal decomposition
 thermal degradation
 thermal draft coefficient
 thermal effects
 thermal equilibrium
 thermal inertia

thermal operating level	tunnel furnace
thermal properties	tunnel tests
thermally thick	turbulent burning
thermally thin	turbulent burning velocity
thermochemistry	turbulent combustion
thermocouple	turbulent flames
thermogravimetric analysis	turbulent jet flames
thermometer	two stage ignition
thermopile	University of Pittsburgh
through penetration fire stop	unpiloted ignition
time to ignition	unpiloted ignition toxicity
time to sustained burning	urban fires test (upitt)
torch	urban fuels
total flux meter	van der waals effects
total heat flux	vertical furnace
total heat release	visible smoke
total smoke release	volume flame spread
toxic fire hazard	wall fires
toxic hazard	weight loss rate
toxic potency	wood smoke
toxic potency test	xp2 chamber test
toxicity	zone models
toxicity tests	

The American Society for Testing and Materials takes no position respecting the validity of any patent rights asserted in connection with any item mentioned in this standard. Users of this standard are expressly advised that determination of the validity of any such patent rights, and the risk of infringement of such rights, are entirely their own responsibility.

This standard is subject to revision at any time by the responsible technical committee and must be reviewed every five years and if not revised, either reapproved or withdrawn. Your comments are invited either for revision of this standard or for additional standards and should be addressed to ASTM Headquarters. Your comments will receive careful consideration at a meeting of the responsible technical committee, which you may attend. If you feel that your comments have not received a fair hearing you should make your views known to the ASTM Committee on Standards, at the address shown below.

This standard is copyrighted by ASTM, 100 Barr Harbor Drive, PO Box C700, West Conshohocken, PA 19428-2959, United States. Individual reprints (single or multiple copies) of this standard may be obtained by contacting ASTM at the above address or at 610-832-9585 (phone), 610-832-9555 (fax), or service@astm.org (e-mail); or through the ASTM website (www.astm.org).